



PRO Wheel Bore Polishing Kit

Full instructions with photos: www.PinewoodPro.com

090122

1. Polish the Wheel Bore

- Insert the rod end of a cotton spear into your drill and lock it down
- Dip the cotton spear into the Micro Polisher Vial
- Start your drill slowly while inserting the spear into the wheel bore
- With the cotton spear spinning, move the spear in and out for about 15-20 seconds
- Change spears and repeat for the other three wheels

2. Clean the Wheel Bore

- The Micro Polish is abrasive. You **MUST thoroughly wash all remnants of polish out of your wheels.**
- Place the wheel under the faucet and run water so the water pressure cleans the wheel bore
- Dry the wheel and bore thoroughly. If you are in a hurry, use a hair dryer for a few minutes.

3. Graphite the Wheel Bore

- Once the wheel is dry, put some graphite on a piece of paper and rub a clean spear into the graphite.
- Carefully put the spear into your drill and lock it down.
- Start your drill slowly as you insert the spear into the wheel bore. Then speed up the drill while pulling the spear in and out to cover the entire wheel bore. Add more graphite and repeat for the other three wheels.

Safety First!

- Keep all contents of this package out of reach of children.
- Do not put your face near the drill as you polish and graphite the bore.
- Wear a face mask and safety glasses. Do not get polish in your eye.